

**MUL-340 UNIVERSAL COMBINATION NONMETALLIC STRAPPING TOOL
PARTS LIST**

KEY No.	PART DESCRIPTION	QUTY
340-01	Sealing Handle	1
340-02	Spring Pin 1/4 x 5/8	2
340-03	Button Cap Screw M6x16	1
340-04	Sealing Head	1
340-05	Bearing	1
340-06	Shaft	1
340-07	E-Ring 1/2	2
340-08	Main Spring	1
340-09	Screw	1
340-10	Frame	1
340-11	Plane Washer 6	2
340-12	Screw	2
340-14	Bushing	1
340-15	Plane Bearing	1
340-16	Roller	1
340-17	Nut M5	1
340-18	Set Screw M5x16	1
340-19	Shaft	1
340-20	Tension Pawl	1
340-21	Base	1
340-22	Screw	2
340-23	Set Screw M4x6	2
340-24	Cap Screw M8x16	1
340-25	Button Head Cap Screw M5x8	1
340-26	Arm	1
340-27	Return Arm	1
340-28	E-Ring 7/16	1
340-29	Plane Washer 12	1
340-30	Ratchet Wheel	1
340-31	E-Ring 3/16	1
340-32	Tension Pawl Long	1
340-33	Knob	2
340-34	Tension Handle	1
340-35	Spring	1
340-36	Pin	1
340-37	Shaft	1
340-38	Gripper Head	1
340-39	Tension Housing	1
340-40	Cutter	1
340-41	Handle	1
340-42	Cover	1
340-43	Windlass	1
340-44	Button Head Cap Screw M4x10	2
340-45	Shaft	1
340-46	E-Ring 5/16	2
340-47	Spring Pin 3/32x1	1
340-48	Punch Spring	1
340-49	Punch Head	1
340-50	Lock Guide	1
340-51	Lock Guide Spring	1
340-52	Guide Spring	1
340-53	Plane Washer 4	2
340-54	Button Head Cap Screw M4x6	2
340-55	Side Cover	1
340-56	Pin	1
340-57	Tension Pawl Spring	1
340-61	Plate	1
340-62	Plate	1